

## Illustration of Camera Functions

Model No.: VSDPK720P (720P Pocket DVR)

Step 1: Insert a micro-SD card (Max 16GB).

Step 2: Hold on the top button for 3 seconds, it will power on and record audio & video automatically with red indicator flashes.

Press the top button once to stop recording, save the video and go into stand-by mode. Hold on the top button for 3 seconds again, it will automatically turns off.

Step 3: If you want recording more videos, just press the top button again in stand-by mode.

Step 4: When you finish recording, just plug the USB into a computer to view the files.

However, as USB transferring speed is limited, it is strongly suggested that you may copy the files to the computer for playing.

Congratulations! Now you know how to use the pocket camera.

Important note:

1. You may select D1(720\*480 pixel) or HD(1280\*720 pixel)
2. In case if the red indicator flashes quickly, there are two possibilities. It may be that you did not insert any micro-SD and it will turn off; or the micro-SD is full.
3. If the power is low, plug the USB into computer to charge it. The red indicator will flash during charging. And it will be always on when the charging is finished.
4. Sometimes the pocket DV will crash for wrong operation. Now just use a pin to touch into "reset" hole to restart.

Specifications:

Size	11.7*3*1.6CM only
Weight	32g only
View Angle	72 degrees
Video Format	AVI
Frame Rate	30fps
Video Resolution	1280*720 (HIGH PIXEL)MORE THAN 3HOURS RECORD
	720*480 (LOW PIXEL)UP TO 3.5 HOURS RECORD
Audio	Support
Micro SD Card Support	2G to 16GB
Battery	530MAH Lithium-ion battery
Consumption Current	160mA
Operating Temperature	0 - 65 °C / 32 - 149 °F